

Mount the battery unit to the bottom mounting bracket (on the keyhole slot) using mount bolts, and fasten the seismic screws (torque to 4.1 ft-lb) according to the IQ Battery 5P Quick Install Guide.

Web: <https://solar.cgprotection.com>