

What is amasstore gtx3000 5?

User manual AMASSTORE GTX3000 5 Product Overview 5.1 Brief Introduction Product overview The AMASSTORE GTX3000 high-voltage lithium battery energy storage system consisting of 4-10 pcs battery modules (51.2V / 50AH) and one BCU (Battery Control Unit) in series with an operating voltage range between 180V--700V. It is Copyright &#169;...

How to turn on amasstore gtx3000 battery system?

Page 23 User manual AMASSTORE GTX3000 5.3.3.1 Power Switch Main MCB: Power on /off the AMASSTORE GTX3000 battery system. 5.3.3.2 Start Button 1?Close the Power Switch, press start button more than 3s and then release the button, LED will lights from L5 to L1, and then enters to automatic coding while all LED lights (L5 lights as purple).

What are amasstore gtx3000 operation precautions?

Page 9 User manual AMASSTORE GTX3000 Operation Precautions tems that could product a short circuit before installation and handling ect battery from power/load and then power off battery before installation and maintenance. package. Packaged batteries should not be stacked more than specified number stipulated on the package.

How do I charge my amasstore gtx3000 2?

Page 60 User manual AMASSTORE GTX3000 2? For battery modules with a long inventory time, charge the new module to 100% SOC with a charger (charge voltage is 56.16Vdc / 25A, cut off when current less than 2.5A), and charge the existing system to 100% SOC.

How to connect amasstore gtx3000 EV?

Page 50 User manual AMASSTORE GTX3000 Step 9 Electrical connections. 1?Prepare power cable on side You are advised to use the EV power cable with size 6mm<sup>2</sup> or 9AWG (1500V, 25A) and length min.1500mm. (2) 1: Positive metal contact 3: Positive connector (1)...

What is a gtx3000-h battery system?

SOFARSOLAR's high-voltage battery systemconsists of 4 to 10 GTX3000-H stackable battery modules,and one GTX 3000-BCU (Battery Control Unit). Up to four stacks can be connected in parallel. The GTX 3000- H battery system is compatible with SOFARSOLAR's HYD 5K...20KTL hybrid and ME 5K...20KTL battery inverter series.

Sofar GTX3000-H Amass-store Lithium. LIP (LiFePO<sub>4</sub>) Power: 3kW Battery Usable Energy: 3kWh Size: 610 x 236 x 812 mm Weight: 120 kg. Facebook. info@solarlinkaustralia 1800 155 597 Monday - Friday: 9am - 5pm ...

View and Download Sofar solar AMASSTORE GTX3000 Series user manual online. Lithium-Ion Storage Battery. AMASSTORE GTX3000 Series camera accessories pdf manual download. Also for: Amasstore gtx3000-h4, ...

Ein AMASS STORE BATTERY-GTX3000 Powerbank-Modul von Sofar Solar ist ein Hochspannungs-Lithium-Batteriesystem mit einem einfachen Stapel und einer einfachen Installation. Die Energiebank erlaubt die Konfiguration von 4 bis 10 ...

Web: <https://solar.cgprotection.com>